

CIM EMT Epoxy Primer

- ☐ Substrate must be clean and dry . No oils, grease or loose debris.
- ☐ **Concrete:** ICRI CSP 4-6 **Steel:** 3-4 mil Profile (SSPC-SP6 non-immersion or SSPC-SP10 immersion)
- ☐ Substrate is in a temperature declining mode, and not in direct sunlight. Record temperatures in space provided below:
- ☐ EMT Epoxy Resin and EMT Hardener mixed with power mixer to a 2:1 ratio.
- ☐ EMT Epoxy Primer mixed to a uniform consistency.

Time: _____ Pot Life Expires: _____
 Mix Time: _____ (Pot Life is 40 Minutes)
 Date: _____
 Batch #: _____
 Batch Location: _____

Enter Temperature and pH information in boxes below:

CIM EMT Hardener	CIM EMT Resin	Floor	Ceiling
North Wall	East Wall	South Wall	West Wall

- ☐ Allow a minimum of 15 minutes induction time for mixed primer before application. (Only if temperatures are 50°F)
- ☐ Monitor the following conditions during the application of the product.

OSA Temperature (min. 50°F)	Substrate Surface Temperature	Dew Point	Humidity %	Time of results (30 min intervals)	
					Prior to mixing at first application
					Pot Emptied

- ☐ Outside Air (OSA) Temperature a minimum of 50°F (10°C) for the duration of the application procedure.
- ☐ Substrate Surface Temperature a minimum of 50°F (10°C) for the duration of the application procedure.
- ☐ Are the OSA and substrate temperatures a minimum of 5°F (3°C) above the Dew Point.
- ☐ The application procedure was done in a temperature declining mode and not in direct sunlight.
- ☐ Allow at least 5 hours at 70°F (21°C) of dry time before applying CIM.
- ☐ Test pH of Primer prior to application of CIM - record results in space above. If pH is above 8 solvent wipe with MEK.
- ☐ Apply CIM within 48 hours of primer application (70°F (21°C))

23 Elm Street
 Peterborough, NH 03458
 Ph: 603.924.9481
 Fx: 603.924.9482
 www.cimindustries.com
 Information@cimind.com